



EJLR-1000 has a common input, marked COM and two outputs, marked with a wave/arrow.

Example:
When ON is received it will activate the left output (O₁). It will be activated for 120 seconds or until ON/OFF is received. ON will deactivate O₁, OFF will activate O₂. Only one (1) output will be activated.

